

# **Quick Start Guide**





**CAUTION!** Always use care and wear appropriate PPE when working with chemicals!

#### **Install and Connect**

- A. Mount unit to wall
- B. Plumb Devices to pumps (air)
- C. Supply system requirements
- D. Pull out E-stop firmly to turn unit ON.
- E. Verify solid ights on all Devices.



#### **System Requirements**

- Compressed Air 10 CFM @ 80 psi
- Electrical 110VAC, 5A
- Water 7 GPM @ 35 psi min

**Example Installation** COMPRESSED AIR 115VAC ALX CONTROLLER CAN-SO-4 CAN-SO-4 AODD AODD AODD **PUMP PUMP** PUMP ≤1/2" >1/2" OUT IN OUT IN OUT



# LITE

# **Quick Start Guide**





CAUTION! Always use care and wear appropriate PPE when working with chemicals!

### **2** Create Users

#### **NOTE: Default Admin Passcode is 1234**

- A. (ADMIN) ► to Users ► ENTER
- B. 00-Create New User ▶ ENTER
- C. Fill out fields
- D. Scan RFID if applicable
- E. (ESC) to exit and (ENTER) to save

# **3** Configure Devices

- A. (ADMIN) ► ( to Devices ► ENTER
- B. Selected device will flash
- C. (ENTER) and fill out all fields
- D. (ESC) to exit  $\triangleright$  (ENTER) to save

## 4 Prime Pumps

- A. ADMIN ► to Devices ► ENTER
- B. Selected a Device ► ENTER
- C. START ► STOP to prime
- D. (ESC) to exit and (ENTER) to save.

## **5** Create Applications

- A. ADMIN ► to Applications ► ENTER
- B. 000-Add New App ► (ENTER)
- C. Type in a unique 3-digit AFF#
- D. to Name: and type a name
- E. 
  to Add dispense step ► ENTER
- F. ← to select Device: ► ↓
- G. to select Step Type:
- H. Enter Time and/or სolume ► (ESC)
- **I. MULTI-STEP**: Repeat D-G to add more steps
- J. ESC to exit and ENTER to save

## 6 Set Date & Time

- A. ADMIN ► to Set Date & Time ► ENTER
- B. to edit each setting
- C. (ESC) to exit

# 7 Configure Unit

- A. ADMIN ► to Unit Confis ► ENTER
- B. to edit each setting
- C. ESC to exit

#### More Information

Please reference the User Manual provided with product or contact Clean Logix at (616)-438-9200 or sales@clean-logix.com

# 8 Configure Reports

A. Refer to User Manual for more information