



CAUTION! Always use care and wear appropriate PPE when working with chemicals!

1 Set Up Chemicals

- A. Go to **CleanIntel.com**
- B. Select Chemical Manufacturer Site
- C. Go to the **Sites** tab
- D. Select **Chemicals** next to the new site
- E. Add all chemicals to the site

NOTE: Specific pricing can be set per site.

2 Create Users

- A. Go to **CleanIntel.com**
- B. Select the site
- C. Go to the **Site Information**

Plant Users:

- D. Select **Plant Users**
- E. Click **New Plant User**
- F. Enter a name and 4-digit login code. RFID can be entered manually online or scanned at the unit.
- G. Select User Access level and click **Create**

Web Users:

If a user already has a CleanIntel login tied to their email address, you must contact Clean Logix to authorize access to the new site.

- D. Select **Web Users**
- E. Click **New User**
- F. Enter name, email, password, and access Level
- G. The new user will receive an activation email with directions to activate the account

3 Set Up Applications

- A. Go to **CleanIntel.com**
- B. Select the site
- C. Go to the **Allocation** tab
- D. Select **Applications**
- E. Click **New App** button
- F. Enter a 4-digit code, name, and location
- G. Add the dispense steps of the Application

Dispense Types:

- **Weight** – Dispenses until the specified weight is achieved. (**NOTE:** Only applicable to Weight-Based ALX-PRO models)
 - **Fixed Time** – Dispenses for the specified amount of time. Reported dispense volume is manually entered.
 - **Calibrated Time** – Dispenses for a calculated amount of time, based on the specified volume. Requires manual calibration of each pump.
- H. Fixed Time: enter chemical, enter time minutes and seconds, enter reporting volume.
 - I. Weight or Calibrated Time: Enter chemical, enter desired volume
 - J. Click **Create App** after all steps are entered

4 Physical Set Up

- A. Install the unit

Please refer to the User Manual provided to you with the unit.



CAUTION! Always use care and wear appropriate PPE when working with chemicals!

5 Sync the Unit


- A. Ensure the unit is powered ON
- B. Click **Sync** on the unit's home screen

NOTE: If the Sync fails, check your cell router connection. Ensure it is plugged in, powered on, and has signal.

6 Assign Pumps

- A. Go to the Admin menu
- B. From the Settings tab select **Pumps**
- C. Select a pump and click **Identify**
- D. Locate the pump solenoid controller with a flashing light
- E. Assign the selected pump to the chemical
- F. Select the manifold for the chemical
- G. Settings are saved on entry
- H. Get a container ready, click **Prime Pump**
 - Press **START** to begin priming the pump and press **STOP** when chemical begins to flow from the dispense hose
- G. Repeat for every pump

More Information



Please reference the User Manual provided with product or contact Clean Logix at **(616)-438-9200** or **sales@clean-logix.com**

7 Calibrate Scale*

**ONLY APPLICABLE ON SYSTEMS WITH A SCALE*

- A. Go to the Admin menu
- B. Select **Scales**
- C. Select the scale to calibrate
- D. Ensure there is nothing on the scale (except the trays for tower kits)
- E. Click **Tare**
- F. Place a weight (10-30 lbs.) on the scale
- G. Use keypad to enter weight
- H. Click **Measure Now**
- I. Verify Live Weight, if incorrect - remove weight and begin at step E.
- J. Repeat for additional scales, if applicable

8 Calibrate Pumps

**NOT NECESSARY FOR SYSTEMS USING EXCLUSIVELY WEIGHT-BASED APPLICATIONS*

- A. Get a container ready for dispensing into
- B. Go to the Admin menu
- C. Select **Pumps**
- D. Select the pump to be calibrated
- E. Select Time Cal or Weight Cal
- F. Follow the on-screen instructions
- G. Add two calibration points for time based
 - Ensure calibration points are significantly different and encompass volumes the pump will be dispensing
- H. Repeat for all other pumps

NOTE: To perform a water flush at any time, enable the "Water Flush" function from General Settings.