Venturi Airless Foamer Quick Start Guide





CAUTION! Always use care and wear appropriate PPE when working with chemicals!

1 Install and Connect

- A. Mount SLX enclosure to wall
- B. Flush supply lines
- C. Connect water supply line (3/4" FNPT)
- D. Connect discharge hose
- E. Connect airless foam wand
- F. Place chemical container below unit and drop in suction line







2 Dilution

- A. Select a metering tip for desired dilution ratio
- B. Install the metering tip by screwing it onto the hose barb for the chemical inlet
- C. Install chemical suction line to hose barb
- D. Connect suction line to chemical solution


Metering Tip Calculator
Mobile App:



3 Operation

- A. Take hold of spray wand
- B. Open discharge ball valve
- C. Open water supply valve unit will spray
- D. Verify water pressure is *at least* 35 PSI
- E. Foam equipment and rinse before it dries
- F. When complete, turn off supply valves
- G. Store rinsed hose depressurized, with discharge valve open, and coiled properly to prevent kinks

Venturi Airless Foamer Quick Start Guide





Please contact Clean Logix at:

(616)-438-9200 or sales@clean-logix.com

View User Manual for More Details:



Insert Size	Flow Rate (GPM)	(1) Insert #	(2) Wand #
V14	1.4	M2325	M2516
V25	2.5	M2691	M2517