


**CAUTION!** Wear appropriate PPE when working with chemicals. Backflow prevention required.

## 1 Install and Connect

- Mount SLX enclosure to wall
- Flush supply lines
- Install backflow prevention per local guidelines
- Connect supply lines:
  - Compressed air (1/4" NPT)
  - Water (3/4" NPT)
- Connect discharge hoses
- Place chemical containers below unit

### Example Installation



## 2 Dilution

- Select a metering tip for desired dilution ratio
- Install the metering tip by screwing it onto the hose barb for each chemical inlet
- Install chemical suction lines to hose barbs
- Connect suction lines to chemical solutions


**Metering Tip Calculator  
Mobile App:**



## 3 Operation

- Take hold of spray wand for either system
- Open discharge ball valve
- Open water supply valve - unit will spray
- Verify water pressure is **at least** 35 PSI
- Open air supply valve for each foamer individually
- Adjust air pressure to alter foam quality for each
- Foam equipment, from bottom to top, and rinse before it dries
- When complete, turn off supply valves
- Store hose depressurized, with discharge valve open, and coiled properly to prevent kinks

**CAUTION!** Wear appropriate PPE when working with chemicals. Backflow prevention required.



Purchase Replacement Parts:



View User Manual for More Details:

